

# lockup-mate®

*MITSUBISHI TRITON MQ 2.4L DIESEL (2016-2018)*



**MM**  
**4X4**

[mm4x4.com.au](http://mm4x4.com.au)

**SUNVISOR QUICK REFERENCE CARD**

### CONFIGURATION MODE

Engine OFF, Ignition ON, place into **SPORT mode**, and press **LED/Switch**, or press and hold for 10 seconds to reset to factory defaults

#	PARAMETER	VALUE
1	LOCKUP SENSITIVITY	RANGE 60-160 <b>DEFAULT (100)</b>
2	MINIMUM LOCKUP GEAR	RANGE 10-50 (= 1 <sup>ST</sup> -5 <sup>TH</sup> ) <b>DEFAULT 2<sup>ND</sup></b>
3	LED BRIGHTNESS*	RANGE 0-100 (%) <b>DEFAULT(DAY 80,NIGHT 3)</b>
4	WARMUP TEMP	RANGE 20-100 (°C) <b>DEFAULT (40°C)</b>
5	DRIVE ACTIVATION SPEED	40-120 (kph) <b>DEFAULT (75 kph)</b>

\*Day-time and Night-time can be individually set. Use Headlight switch to select

### DRIVING MODE TOGGLES

ON/OFF	PRESS LED/Switch
BRIGHT LED	PRESS & HOLD 5 SECS
PROTECTION MODE	PRESS & HOLD 10 SECS



### SELF DIAGNOSTIC MODE

Engine OFF, Ignition ON, **SPORT mode**, and press and hold **LED/Switch 5 secs** (Parameters 1-6 = approx. 80, 80, 100, 15, 30, 55)

## SUNVISOR QUICK REFERENCE CARD